



Montagematerial / Mounting Material

Nr./ No.	Artikel / Article	Dim.	#
1	Sechskant-Schraube / Hexagonal screw	M 10 x 110	2
2	Sechskant-Schraube / Hexagonal screw	M 10 x 100	4
3	Sechskant-Schraube / Hexagonal screw	M 10 x 35	2
4	Sechskant-Schraube / Hexagonal screw	M 8 x 55	5
5	Sechskant-Schraube / Hexagonal screw	M 8 x 40	4
6	Sechskant-Schraube / Hexagonal screw	M 8 x 30	4
7	Sechskant-Schraube / Hexagonal screw	M 10 x 55	1
8	Ringkopf-Mutter / Ring-headed screw nut	M 10	3
9	Stop Mutter / Stop-screw nut	M 10	6
10	Stop Mutter / Stop-screw nut	M 8	13
13	Beilagscheibe / Flat washer	M 10 x 30	19
14	Beilagscheibe / Flat washer	M 8 x 20	12
16	Abdeckung / Plug connection	50 x 50	2
18	Niro Hülse / Stainless steel bush	80 x 15/1	2
19	Abdeckung / Plug connection	40 x 20	2

Alpine Rescue Equipment
TYROMONT

**RETTUNGSANHÄNGER
RESCUE TRAILER**

MG / 11.12.2014

Version: 3.0

93152 / 93153 / 93157

Montageanleitung - Kufen für Anhänger
Mounting Instruction - Runners for Trailer