



### Montagematerial / Mounting Material

Nr./No.	Artikel / Article	Dim.	#
1	Sechskant-Schraube / Hexagonal screw	M 10 x 110	2
2	Sechskant-Schraube / Hexagonal screw	M 10 x 100	4
3	Sechskant-Schraube / Hexagonal screw	M 10 x 35	2
4	Sechskant-Schraube / Hexagonal screw	M 8 x 55	5
5	Sechskant-Schraube / Hexagonal screw	M 8 x 40	4
6	Sechskant-Schraube / Hexagonal screw	M 8 x 25	4
7	Sechskant-Schraube / Hexagonal screw	M 10 x 55	1
8	Ringkopf-Mutter / Ring-headed nut	M 10	3
9	Stop Mutter / Lock nut	M 10	6
10	Stop Mutter / Lock nut	M 8	13
13	Beilagscheibe / Flat washer	M 10 x 30	15
14	Beilagscheibe / Flat washer	M 8 x 20	12
15	Beilagscheibe / Flat washer	M10 x 20	4
18	Niro Hülse / Stainless steel bush	80 x 15/2	2

#### Bereits montiert / Already mounted

16	Abdeckung / Plug connection	50 x 50	2
19	Abdeckung / Plug connection	40 x 20	2

Alpine Rescue Equipment  
**TYROMONT**

## RETTUNGSANHÄNGER RESCUE TRAILER

MG / 19.02.2019

Version: 5.0

**93152 / 93153 / 93157**

Montageanleitung - Kufen für Anhänger  
Mounting Instruction - Runners for Trailer