



Inspection Report for Helicopter Rescue Bag



- In addition to the inspections before each use (by a trained person), the product must be subjected to an annual detailed inspection in accordance with the regulations for PPE by the manufacturer or a qualified person.
- This review must be documented and recorded in writing.
- The inspection instructions provided by the manufacturer must be used to check the rescue bag.

Helicopter Rescue Bag data

Company/User			
Model			
Article number P/N		Serial number S/N	
Year of production		First use	



Good condition



Monitor condition



Do not use, retire

N/A

Not applicable



N/A

✓ Prior Control

- Make sure that the maximum service life of the product has not been exceeded.
- Make sure that the serial number and the CE marking are present and legible.
- Compare the product with a new mountain bag to ensure that no changes have been made.

✓ Checking the Storage Space

- Storage must be dry and protected from direct sunlight and at room temperature.
- The storage place must be protected from any kind of aggressive chemicals that can attack textile materials.

✓ Inspection of the Carrying Braid or Straps for Suspension Fixation

- Checking whether there is any damage to the belts or the fittings between the belts.
- Checking whether there are any cuts, tears or other mechanical damage to the safety belts.
- Checking the internal strapping and its fittings for damage.

✓ Inspection of the outer Belts and Buckles

- Any kind of damage or contamination by technical liquids on one of the strapping belts or on the fittings between the belts.
- Defective belts and buckles must be replaced with original parts.

✓ Inspection of the 10- Strand Suspension (12- Strand Suspension)

- Any kind of violation of the strands and seams on the end loops.
- Any contamination by technical liquids.
- A wear of >5% of the metal fittings (run-in marks, notches).

✓ Inspection of the Velcro Fastener

- Damage or detachment of the Velcro from the fabric cover >50 mm.
- Any contamination by technical fluids of the Velcro larger than 20 x 20 mm.
- Any kind of cuts, cracks or other mechanical damage to the Velcro structure longer than 50 mm.

✓ Inspection of the Zippers

- Defective zippers must be replaced with original parts.

✓ Inspection of Miscellaneous Attachments

Verifier details

Checked from			
Company			
Date of review		Date of the next check	

Is the product suitable for further use

YES

NO

Signature