



Rescue Sling TYRloop



The **Rescue Sling TYRloop** is used for rescuing people in water and land emergency situations.

Due to the **one-size closure system** (Velcro/hook closure of the belt), the adjustment to the size of the person to be rescued is automatic or self-adjusting, and the patient's own weight ensures that it is securely wrapped around the patient.

The **integrated flotation device** with three external handholds allows rescue from water emergency situations.

This does not serve as a buoyancy aid for the patient, it only allows the rescue loop to float up.

Take care to avoid suspension trauma of the person to be rescued.



Art. No.	93359	
Dimensions	Length total:	2.200mm
	Length loop:	900mm
Weight	0,7 kg	
Remarks	ÖNORM EN 1498 class A, EASA CM-CS-005 simple PCDS	